

# **WARRIOR® TRS**

## **TOILET REPAIR SET**

D-I-Y REPAIR SET FOR TOILET WATER LEAKAGE; NO HACKING REQUIRED.





**WARRIOR TRS- TOILET REPAIR SET** is a complete set of materials designed for D-I-Y (Do It Yourself) repair of toilet water leakage. It is the simplest and most economical product kit that allows everyone to stop toilet water leakage in a professional way.

TRS- TOILET REPAIR SET consists of:-

#### **WARRIOR SS-10 SHOWER SEAL**

Function: Invisible and deep penetrating water repellent. Will penetrate and seal up the micro pores and cracks. Minimal stain and traces on surface.

## **WARRIOR W-1D CEMENT STRENGTHENER**

Function: Significantly increases the bonding strength, hardness and water tightness of the tile grout. Can be poured into cracks to seal up the gaps.

**Tile Grout**: Better bonding strength than normal white cement. Minimal shrinkage or crack. Also included: Paint brush, plastic scrapper, plastic cup

# WARRIOR 武士牌®

# **WARRIOR® TRS**

## **TOILET REPAIR SET**

### D-I-Y REPAIR SET FOR TOILET WATER LEAKAGE; NO HACKING REQUIRED.

#### **APPLICATION METHOD**

- 1. Clean the surface to be treated. Remove any faulty, loose or cracked tile joint.
- 2. Allow the surface to dry for one day (do not use the toilet).
- 3. Apply, by brush, **SS10** generously onto the entire tile joint.
- 4. After 30 minute, apply 2nd coat of **SS10**. Wipe away the chemical residue on the tile surface.
- 5. After 30 minute, **add W-1D to tile grout** cement gradually and mix until a sticky homogenous paste is achieved. Press the grout cement paste into the tile joint firmly.
- 6. Wipe away the grout stain on the tile surface.
- 7. Allow ONE DAY for chemical curing and cement setting.
- 8. JOB DONE.

#### Reminder:

Always do a patch test of SS10 (apply a drop on tile at a remote corner, and check for any undesirable surface stain the next day) prior to full scale application.

#### **CONTENT**

WARRIOR W-1D CEMENT STRENGTHENER (500g)
WARRIOR SS-10 SHOWER SEAL (500g)
TILE GROUT (500g)
PLASTIC SCRAPPER
MIXING CUP
GLOVES
INSTRUCTION MANUAL